



1	Phone Screen	Shows a screen with backlight that enables you to view menus and data.
2	Power LED Indicator	Indicates call status, message status and phone's system status.
3	Line Keys	Access your phone lines and features.
4	Soft Keys	Access the function displayed on the screen above the soft keys.
5	Keypad Keys	Allow you to enter numbers, letters, and special characters. If a menu item has an index number, you can use the keypad keys to select the item.
6	HEADSET Key	Toggles the headset mode on or off. The LED indicator glows green when the headset mode is activated.
	MUTE Key	Toggles the microphone on or off. The LED indicator glows green when the mute feature is activated.
	MESSAGE Key	Accesses your voice messages.
	HOLD Key	Places a call on hold or resumes a held call.
	REDIAL Key	Redials a previously dialed number.
	TRANSFER Key	Transfers a call.
7	Speakerphone Key	Toggles the speakerphone (hands-free) mode or not. The LED indicator glows green when the speakerphone is activated.
8	Volume Key	Adjusts the volume of handset, headset and speaker.
9	Navigation Keys	• Scroll through information or options displayed on the screen. • Access History and Directory
	OK Key	Confirms actions or answers incoming calls.
	Cancel Key	Cancels actions or rejects incoming calls.
10	Speaker	Provides hands-free (speakerphone) audio output.
11	Reversible Tab	Secures the handset in the handset cradle when the phone is mounted vertically.
12	Hookswitch	Connects or disconnects the phone from the phone line.